

## AIR MANAGEMENT EQUIPMENT

**AirWalls** can be used to isolate an area that will not be heated or partition off areas that will be heated in a progression. The 6' x 10' AirWall works great in stairwells and hallways, while the 12' x 10' AirWall can isolate untreated areas like a kitchen, living room, family room, etc.



The AirWall requires a 16" Multifan, adapter, and 20" transition. Made of fire-resistant materials. Both 6' x 10' and 12' x 10' AirWalls can be used individually or zipped together to build false walls or isolate larger spaces.



**Wall Edge Duct** is designed to direct heat on high bed bug infestation zones through the holes in the duct aimed at wall edges, baseboards, and carpet tacks, etc.

The Wall Edge Duct requires a 16" Multifan, adapter, and 20" transition. Made of fire-resistant materials.